

SKODA ROUND EMBLEM INSTALL GUIDE:

SET CONTAINS : emblem + isopropanol cleaner cloth + 3M Primer 94 stick

1 emblem needs **1x** isopropanol cloth and **1x** 3M primer 94 stick

2 emblems need **2x** isopropanol clothes and **1x** 3M primer 94 stick

1) Make sure, installing temperature is min. 18 °C (if you will install it in the lower temperature, emblem will not stick correctly !)

2) Installing area clean with the isopropanol cloth and wait 5 mins

3) Now most important part: use „3M Primer 94“ stick on the install area, like on this video:

<https://youtu.be/d0MohnZGlws>

Paint the primer **ONLY ONCE (!)** , do not make more layers over and over. Just **ONE** layer please.

4) **IMPORTANT:** Now wait at least 10mins

5) Take off the double-tape cover from the emblem and stick it carefully on the car.
DO NOT slam in the emblem ! Just use pressure with hand to press it on the car like on this video: <https://youtu.be/AL5JE7xLFGc>

6) DO NOT clean the emblems with high-pressure water cleaner (Karcher/Wap/etc...).

Always clean it with hand wash only